

## Transfers

1	Min Oil Level	Oil tank	Peel backing paper and apply adhesive side down, rub well, leave 10 secs and peel off backing. Apply varnish
2	Piled Arms & Garter	Centre of tool box and oil tank	
3	Piled Arms 650 twin	Rear mudguard	
4	Made in England	Bottom of rear mudguard	
Water slide - soak transfer in water (washing up liquid may help) until it starts to release. Slide face up into position. Leave to dry for 24 hours. Apply varnish.			

### Transfers 1 & 2

Note that the top of the oil tank and tool box are not horizontal. If aligned with the top they will look wrong when the bike is on its wheels. See template for level. (Sorry I could not find a good blue oil tank)



### Transfer 2 toolbox



Transfers 3

Again, sorry could not find blue rear mudguard

